



Designer's Choice

Traditional



Modified Traditional



Contemporary
























Modern















Door Profiles























Panel Profiles

- P1  Dropped Scoop
- P2  Medium Harvard
- P3  Tuscan
- P4  Hardwood Flat
- P5  Scoop
- P6  Terraced
- P7  Victorian
- P8  Deep Scoop
- P9  Round Out
- P10  Long Slant
- P11  Medium Slant
- P12  Short French
- P13  Pillow
- P14  Small Ogee
- P15  Square
- P16  Notch Scoop
- P17  French
- P20  Santa Fe
- P21  Stepped Bead
- P24  Short's and Bead
- P25  Tuscan/App. Mold

Stile and Rail Profiles

- A  1/4" Bead
- B  Small Ogee
- C  Square
- D  Bevel
- E  French Ogee
- F  Notch
- G  Ctr Square
- H  Medium Ogee
- K  Santa Fe II
- L  Double Bead

Edge Profiles

- E1  Ogee
- E2  Scoop
- E2f  Finger Pull
- E3  3/8" Round
- E4  Square
- E5  Bevel
- E6  Inset Round
- E7  1/4" Round
- E8  1/4" Drop Round
- E9  3/8" Drop Round
- E10  Tuscan
- E11  Notch
- E12  Pillow
- E13  Long Ogee
- E14  French Ogee
- E15  Bead and Scoop
- E16  Terraced Scoop
- E17  Utah Ogee
- E18  1/8" Round
- E19  Simple Step
- E20  Santa Fe II
- E21  Inset Oval